



TOLL FREE: 1-866-597-0728

Mon.-Fri. 7:30am - 4:00pm PT

www.glorystar.tv

How to scan for 3ABN Dare To Dream, 3ABN Latino Radio and 3ABN Proclaim

3ABN has added new channels 3ABN Dare to Dream (D2D) and 3ABN Latino Radio. The 3ABN Proclaim channel has been moved to a new frequency. Current Glorystar receivers will be automatically updated to receive these channels. Automatic updating models are: GEOSATpro DVR1100 / DSR100 / DSR200.

If you have an older receiver (Manhattan, Topfield, Fortec Star) the best method for updating your receiver for all of the Adventist Channels is to delete current programming, scan for the new channels then delete the unwanted channels. Free step by step instructions are provided below for receivers distributed by Adventist broadcasters.

We highly recommend the purchase of a complete Glorystar system or upgrade your old receiver with a new Glorystar receiver. Glorystar receivers have all channel changes in place and automatically update to add new channels as they become available. Please call us at 866-597-0728 and ask the sales team for a Glorystar system or receiver upgrade to watch all the current channels and automatically add any new Glorystar channels.

Fortec Star Mercury II - Glorystar System

Important Notice: Your FREE Adventist channel scanning instructions are provided below. Telephone assistance may be available at an additional charge for "Out Of Warranty" equipment.

If you require additional assistance, please contact the company or broadcaster where you originally purchased your satellite system.

1. Using your Fortec Star Mercury II remote control press "Menu" button to go to "Installation" screen
2. Press the Channel down button to highlight "Factory Reset"
3. Press OK button to go to "Factory Reset" screen with Factory Reset line highlighted
4. Press OK button. A pop up window displaying "Are You Sure?" with "No" highlighted yellow
5. Press VOL down button to highlight "Yes" with yellow
6. Press OK button
7. When Language screen appears, turn off master power switch on back of receiver or unplug receiver from AC power outlet for 10 seconds
8. Turn the receiver back on or plug the receiver back into AC power outlet. "Language" Menu will appear
9. Press "Menu" to go to "Installation" screen with "Antenna Setup" highlighted
10. Press OK button to enter "Antenna Setup" screen
11. If needed, press VOL down button (the button that points left) to select "Galaxy25 Ku 97.0W or IA5/KU 97.0W"
12. Press the Channel down button to highlight "LNB TYPE"
13. Press VOL up button to display "LNB-10750"
14. Press the Channel down button to highlight "0/22kHz" line and press the VOL up right arrow button to display On
15. Press the Channel down button to highlight "Switch" line and press the VOL up right arrow button to display DiSEqC 1.0

How to scan for 3ABN Dare To Dream, 3ABN Latino Radio and 3ABN Proclaim (continued)

16. Press the Channel down button to highlight "Input" line and press the VOL up right arrow button to display LNB 2
17. Press Menu button to go back to "INSTALLATION" screen, prompt will display "Saving"
18. Press the Channel down button twice to highlight "TP SCAN"
19. Press OK button to go to "TP SCAN" screen
20. Press the Channel down button to highlight "FREQUENCY"
21. Using the numbers buttons on the remote control enter 11842
22. Press Channel down button to highlight "POLARITY" and push the Volume up button (the button that points to the right) it should display "Horizontal"
23. Press Channel down to "SYMBOLRATE"
24. With the number buttons on the remote control enter the numbers 22000
25. Press Channel down to "Save Edit" line and press OK to store. Store prompt will show for a moment
26. On the bottom of the screen you will see two bars, one says "SIGNAL LEVEL" and the other "SIGNAL QUALITY"
27. If you have the "Signal Quality" bar with the highest strength (at least 50%), press Yellow button
28. When Channel Scan is completed, pop up window displaying "Do you want to save?" with "Yes" highlighted yellow
29. Press OK button to save. Programming will automatically be displayed
30. Press Menu button to enter "INSTALLATION" screen
31. Press the Channel up or down to highlight "TP SCAN"
32. Press OK button to go to "TP SCAN" screen
33. Press the Channel down button to highlight "FREQUENCY"
34. Using the numbers buttons on the remote control enter 12060
35. Press Channel down button to highlight "POLARITY" and if necessary push the Volume up button (the button that points to the right) it should display "Horizontal"
36. Press Channel down to "SYMBOLRATE"
37. With the number buttons on the remote control enter the numbers 22000 if necessary
38. Press Channel down to "Save Edit" line and press OK to store. Store prompt will show for a moment.
39. On the bottom of the screen you will see two bars, one says "SIGNAL LEVEL" and the other "SIGNAL QUALITY".
40. Verify the "Signal Quality" bar with the highest strength of at least 50% or better. If not, you may need to fine-tune the dish and balance between the 11842 and the 12060 frequencies before scanning the new channel.
41. Press Yellow button to scan new channels
42. When Channel Scan is completed, pop up window displaying "Do you want to save?" with "Yes" highlighted yellow
43. Press OK button to save. Programming will automatically be displayed

Optional steps: If you would like to view all available free programming from this satellite (this will include secular and international programming)

There are approximately 200 TV stations and 100 Radio stations on this satellite

44. Press P.SCAN button under blue Timer button
45. Press Channel up button to "Mode" line and push the Volume up button to display Scan FTA
46. Press Channel down button to Start Scan line and press the OK button

How to scan for 3ABN Dare To Dream, 3ABN Latino Radio and 3ABN Proclaim (continued)

47. POWER scan screen will appear and will list all available services on the satellite. Do not interrupt, this process may take up to ten minutes to complete
48. The prompt will show "Do you want to save?" with Yes highlighted yellow
49. Press the OK button to save. Prompt "Saving" will show and Power Scan screen will display. Press exit to view programming

Deleting unwanted channels:

50. Press Ok/List button
51. Press the Blue button to Edit the channel list
52. Press the Channel down button to highlight Delete Channel
53. Press the OK button, a small gray button will appear next to each channel name
54. Use the Channel up and down button to highlight channel to be deleted
55. Press the OK button to mark the channel for deletion, the button will turn red
56. Repeat steps 54 and 55 until all unwanted channels are selected
57. Press the Blue button to DELETE, a prompt will display "Do you want to save?" use Vol down left arrow to select Yes highlighted yellow
58. Press the OK button, saving prompt will appear
59. Press exit to view programming